

No.	Notes	MODEL INPUT AIRFLOW CABINET WIDTH CONFIGURATION	U802VA 050 3 17 MSA/MXA	U802VA 075 3 17 MSA/MXA	U802VA 075 4 21 MSA/MXA	U802VA 100 5 21 MSA/MXA	U802VA 125 5 24 MSA/MXA	
HEAT EXCHANGER, BURNER / MANIFOLD GROUP								
2f		Heat Exchanger Bracket - Left Side	AE-67846-02	AE-67846-02	AE-67846-02	AE-67846-02	AE-67846-02	
2g		Heat Exchanger Bracket - Right Side	AE-67846-02	AE-67846-02	AE-67846-02	AE-67846-02	AE-67846-02	
40	Stk	Heat Exchanger Assembly	AS-61579-13	AS-100560-01	AS-61579-12	AS-61579-04	AS-61579-05	
40a		NOX Burner Inserts	AS-67875-01 (2)	AS-67875-01 (3)	AS-67875-01 (3)	AS-67875-01 (4)	AS-67875-01 (5)	
40b		NOX Insert Retainer	AE-67872-01	AE-67872-02	AE-67872-02	AE-67872-03	AE-67872-04	
42		Burner Assembly (Burner, Support, Brackets, Cover and Bottom Plates, Ignitor Bracket)	AS-104944-01	AS-104944-02	AS-104944-02	AS-104944-03	AS-104944-04	
42		Burner Assembly - NOx variants (Burner, Support, Brackets, Cover and Bottom Plates, Ignitor Bracket)	AS-104944-11	AS-104944-12	AS-104944-12	AS-104944-13	AS-104944-14	
42a	Stk	Burner	AS-60993-02	AS-60993-03	AS-60993-03	AS-60993-04	AS-60993-05	
42b		Burner Support	AE-60997-01	AE-60997-02	AE-60997-02	AE-60997-03	AE-60997-04	
42c		Burner Support Bracket (2)	AE-61588-02	AE-61588-02	AE-61588-02	AE-61588-02	AE-61588-02	
42d		Burner Cover Plate	AE-101080-06	AE-101080-02	AE-101080-02	AE-101080-03	AE-101080-04	
42d		Burner Cover Plate (NOx variants)	AE-101080-16	AE-101080-12	AE-101080-12	AE-101080-13	AE-101080-14	
42e		Burner Bottom Plate	AE-104927-01	AE-104927-02	AE-104927-02	AE-104927-03	AE-104927-04	
42f		Igniter Bracket	AE-61885-02	AE-61885-02	AE-61885-02	AE-61885-02	AE-61885-02	
		Screw - Burner Assembly	63-22153-05 (13)	63-22153-05 (14)	63-22153-05 (14)	63-22153-05 (16)	63-22153-05 (17)	
43		Manifold (w/o Orifices)	81-102427-01	81-102427-02	81-102427-02	81-102427-03	81-102427-04	
		Burner Orifice - Natural Gas	See Orifice Selection Chart					
		Burner Orifice - LP	See Orifice Selection Chart					
		Number of Orifices	(2)	(3)	(3)	(4)	(5)	

No.	Notes	MODEL GAS CODE	U802VA JH	U802VA KH	U802VA KQ		
GAS CONTROLS							
50	Stk	Gas Valve - Natural Gas	60-101921-01	60-101921-01	60-101921-01		
	Stk,2	Gas Valve - LP	See Note 2	See Note 2	See Note 2		
51	Stk	Integrated Furnace Control Board (IFC)	62-104061-02	62-104061-04	62-104061-05		
		Memory Module for IFC	See Electric Group	See Electric Group	See Electric Group		
52	Stk	Flame Sensor	62-23543-01	62-23543-01	62-23543-01		
53	Stk	Spark Ignitor	62-24164-03	62-24164-03	62-24164-03		
	Stk	LP Conversion Kit - U.S./Canadian Models	FP-32	FP-32	FP-32		

No.	Notes	MODEL GAS CODE	U802VA ALL				
ACCESSORY KIT							
		Outdoor Sensor Kit	RXGY-J02				